

**“L” SHAPED A-1700-PT**  
**FLUID END MODULE AND ACCESSORIES 液力端**

Item	Part No.	Description	Qty per Pump
	LA-8488-1A	Complete Assembly 阀箱总成	3
	LA-8488-1	Fluid Module, Discharge - Studded (included items 1-5)排出阀箱带栓母 (包括第 1 到 5 项)	3
1		Fluid Module - Discharge 排出阀箱	3
2	LA-4016-96	Stud w/Nut - Frame 螺栓带母	12
3	LA-4016-97	Stud w/Nut - Suction Module 螺栓带母	18
4	LA-4016-3	Stud w/Nut - Discharge Manifold 螺栓带母	12
5	LA-4015-2	Stud w/Nut - Valve Cover 螺栓带母	72
	LA-8488-2	Fluid Module, Suction - Studded (included items 5-6)吸入阀箱带栓母 (包括第 5 到 6 项)	3
6		Fluid Module - Suction 吸入阀箱	3
7	LA-2988	Seal - Module 阀箱密封圈	3
8	LA-10-300-201	Seal - Suction Manifold 吸入管汇密封圈	3
9	LA-8488-5	Dowel Pin 定位销	6
10	LA-4475	Threaded Flange 阀盖法兰	6
11	LA-4575	Screw Gland 阀盖压筒 丝箱盘根盒	6
	LA-4675-1A	Valve Cover Plug Assembly (included items 12-15)缸盖堵头总成 (包括第 12 到 15 项)	6
12	LA-4675-1	Plug - Valve Cover 缸盖堵头	6
13	LA-4775	Valve Guide 导向架	6
14	LA-4018-88	Screw - Valve Guide 导向架螺丝	12
15	LA-4700-1	Insert - Valve Guide 导向套衬套	6
16	LA-P129	Seal - Valve Cover Plug 缸盖堵头密封圈	3
17	LA-6488-1	Liner Retainer Flange 缸套调整法兰	3
18	LA-4017-4	Capscrew - Liner Retainer 缸套调整螺丝	24
19	LA-6588-1	Nut - Liner Retainer (Large OD Liner, LA-0284-XX)缸套调整螺母 (缸套大外径)	3
20	LA-8488-7	Set Screw - Liner Retainer 缸套调整螺丝套	9
21	LA-8488-4	Plate - Wear 耐磨垫	3
22	LA-2974-1	Seal - Wear Plate 耐磨垫密封圈	3

